

Assembly Instructions

2007 Wall Mount Bumper Rack (6 Place)

Step 1: Install (12) 1" Black Plastic Caps into Arm Supports

Step 2: Bolt **4 Place Unit** to wall at least 12" from the floor and 38" – 42" apart from one another. Secure to wall using 3/8" anchors.

Step 3: Install **2 Place Top Unit** by sliding into top of 4 Place Unit. Align and bolt to wall using 3/8" anchors.

If you have any questions regarding assembly,
please call Manufacturer's Manufacturer, Inc. at
800-237-6913

