



3610 MULTI-ROLL MASKER ASSEMBLY INSTRUCTIONS

- Step 1 Lay Main Frame Sides on table with Paper Roller Holders facing inside of unit, then bolt Lower Support to Frame Sides using (4) 5/16 x 18 x 1 1/4" bolts, tighten nuts finger tight at this time.
- Step 2 Slide Axle through holes in rear of Frame Sides.
- Step 3 Install three Cutter Bars on front of unit using (6) 1/4" x 20 x 1" bolts, tighten nuts finger tight at this time. Cutter Bars go behind the front legs, see diagram.
- Step 4 Install Cutter Bar springs on to rear of Cutter Bar; there are two notches, one on either end of Cutter Bar.
- Step 5 Install two Rear Wheels on Rear Axle, tap on Axle Caps.
- Step 6 Install two crutch tips on to front of Main Frame Sides.
- Step 7 Tighten all Bolts at this time.
- Step 8 Assemble Paper Roller Hardware, see diagram 1.
- Step 9 Assemble Tape Reel, see diagram 2.

If you have any questions regarding assembly of this product,
Please call Manufacturer's Manufacturer, Inc. at 800-237-6913.